Image processing- OpenCV

OpenCV is an open-source computer vision and machine learning software library

OpenCV was started at Intel 1999 by Gary Bradsky and the first release come out in 2000.

OpenCV-Python is the python library for OpenCV, combining the best qualities of the OpenCV C++ API and the python language.

OpenCV-Python is a library of python bindings designed to solve computer vision problems.


Computer vision, the field that allows computers gaining high-level understanding from digital images or videos. CV is everywhere, whether you realize it or not.

OpenCV was built to provide a common infrastructure for computer vision applications.

The goal of computer vision is to emulate human vision using digital images through three main processing components, executed one after the other:

- 1- Image acquisition
- 2- Image processing
- 3- Image analysis and understanding

As our human visual understanding of world is reflected in our ability to make decisions through what we see.



Some of applications:

- 1- Face recognition. 3- Medical image analysis.
- 2- Character recognition. 4- Remote sensing.
- 5- Security.

Reading & writing an image

- > cv.imread(filename,flag) to read an image from a storage.
- > cv.imshow(window name,Image) to display an image in a window.
- cv.waitkey(delay) is a keyboard binding function. Waits for a pressed key.
- > cv.imwrite(filename,Image) to write and save an image to the storage.
- cv.destroyAllwindows() to destroy the current running window(GUI).

import cv2

```
img=cv2.imread("images/home.jpg") #read an image
#print(img)
```


cv2.imshow("image1", img) #display an image

cv2.waitKey(0)

cv2.imwrite("images/home.png", img) #save an image

cv2.destroyAllWindows()

Output:



Supporting file types

Currently, the following file formats are supported

```
Windows bitmaps - *.bmp, *.dib

JPEG files - *.jpeg, *.jpg, *.jpe

JPEG 2000 files - *.jp2

Portable Network Graphics - *.png

WebP - *.webp

Portable image format - *.pbm, *.pgm, *.ppm

Sun rasters - *.sr, *.ras

TIFF files - *.tiff, *.tif
```


Types of images

- 1. binary image: takes only two values black and white (0 and1) and requires 1 bit/pixel
- 2. Grayscale: contain only brightness information. No color information Contain 8 bits/pixel data (0 to 255)
- 3. Color: three band monochrome image data.8 bits for each of the three-color bands (red, green, blue)
- 4. Multispectral: contain information outside normal human perceptual range.

Understanding Images

Top: grayscale gradient where brighter pixels are closer to 255 and darker pixels are closer to 0.

Bottom: RGB diagram where brighter pixels are closer to the center.



T: Somia AL-Shibah

All images consist of pixels in a grid. A 640 * 480 has 640 rows and 480 columns. There are 640*480=307200 pixels.

In OpenCV color images in the RGB (Red, Green, Blue) color space have a 3-tuple associated with each pixel: (B, G, R). Each value in the BGR 3-tuple has a range of [0,255].

#access the RGB pixel located at y=100, x=50, keeping in mind that

```
import cv2 as c
img=c.imread("images/home.jpg")
px=img[100,100]
print(px)
(B,G,R)=img[100,50]
print("R={}, G={}, B={}".format(R,G,B))

[208 189 182]
R=182 , G=189 , B=208
```

Example: convert to grayscale and binary

```
import cv2 as c
import numpy as np
img=c.imread("images/trees.jpg")
#convert the image to Gray-scale
grayimg=c.cvtColor(img,c.COLOR BGR2GRAY)
#convert the image to binary image by using threshold
ret,binaryimg=c.threshold(grayimg,127,255,c.THRESH_BINARY)
#convert the image to binary image by using threshold
bwimg=np.zeros_like(grayimg)
bwimg[grayimg>140]=255 #threshold is 140
c.imshow("color image", img)
c.imshow("Gray-scale", grayimg)
c.imshow("binary image", binaryimg)
c.imshow("binary image2", bwimg)
c.waitKey(0)
c.destroyAllWindows()
```

Output:





Image shape and size

Img.shape. it returns a tuple of number of rows, columns and channels(if image is color)




T: Somia AL-Shibah

```
import cv2 as c
                                     Convert to Grayscale Image
img=c.imread("images/home.jpg",0)
print("shape->dimensions: ",img.shape)
print("size->numbers of pixels: ",img.size)
print("Type: ",img.dtype)
c.imshow("image", img)
img2=c.imread("images/trees.jpg")
print('image2')
print("shape->dimensions: ",img2.shape)
print("size->numbers of pixels: ",img2.size)
print("Type: ",img2.dtype)
c.imshow("image2", img2)
c.waitKey(0)
c.destroyAllWindows()
shape->dimensions: (311, 472)
size->numbers of pixels: 146792
       uint8
Type:
image2
shape->dimensions: (227, 376, 3)
size->numbers of pixels: 256056
Type:
      uint8
```

Controlling the keyboard

Output :-----→



```
import cv2 as c
import sys
img=c.imread("images/trees.jpg",0)
if img is None:
    print('Failed to read image from file')
    sys.exit(1)
c.imshow("image", img)
# if wait for any key to be pressed to excute next step
k=c.waitKey(0)
if k==27: # wait for ESC key to exit
    c.destroyAllWindows()
elif k==ord('s'): # wait for 's' key to save and exit
    c.imwrite("images/treesgray.png", img)
    c.destroyAllWindows()
```

Reading and Writing Video with OpenCV

```
1
     import cv2
 2
     # Open the input video file
     videoCapture = cv2.VideoCapture('1.mp4')
 3
     # Check if video opened successfully
 4
     if not videoCapture.isOpened():
 5
         print("Error: Could not open video file.")
 6
 7
         exit()
     # Get FPS and frame size from input video
 8
     fps = videoCapture.get(cv2.CAP PROP FPS)
10
     size = (int(videoCapture.get(cv2.CAP PROP FRAME WIDTH)),
11
             int(videoCapture.get(cv2.CAP PROP FRAME HEIGHT)))
     # Create VideoWriter object for output video
12
     videoWriter = cv2.VideoWriter(
13
        '2.mp4', cv2.VideoWriter fourcc(*'mp4v'), fps, size)
14
```

```
Image processing: LAB1
15
      # Read and write frames until video ends
      success, frame = videoCapture.read()
16
17
      while success:
18
          videoWriter.write(frame)  # Write frame to output video
          cv2.imshow('Video Preview', frame) # Display the frame
19
          # Wait for 1 ms and check if 'q' key pressed to quit early
20
21
          if cv2.waitKey(1) == ord('q'):
              break
22
23
          success, frame = videoCapture.read()
24
      # Release resources and close windows
25
     videoCapture.release()
26
     videoWriter.release()
27   cv2.destroyAllWindows()
      print("Video copying completed successfully.")
28
```

Display Live Camera and Exit on Click or Key Press

```
1
     import cv2
     # Global variable to track mouse click
 2
     clicked = False
 3
 4
     # Mouse callback function to detect left mouse button release
 5
     def onMouse(event, x, y, flags, param):
 6
         global clicked
 7
         if event == cv2.EVENT_LBUTTONUP:
             clicked = True # Set flag when user clicks
 8
 9
     # Open default camera (index 0)
10
     cameraCapture = cv2.VideoCapture(0)
     # Create a window to display the video
11
     cv2.namedWindow('MyWindow')
12
     # Set the mouse callback function for the window
13
     cv2.setMouseCallback('MyWindow', onMouse)
14
     print('Showing camera feed. Click window or press any key to stop.')
15
     # Read the first frame from the camera
16
17
     success, frame = cameraCapture.read()
     # Loop to display frames until a key is pressed or the mouse is clicked
18
19
     while success and cv2.waitKey(1) == -1 and not clicked:
         cv2.imshow('MyWindow', frame)
                                               # Show the current frame
20
         success, frame = cameraCapture.read() # Read the next frame
21
22
     cv2.destroyWindow('MyWindow')
```